



OE to Roadwire  
 Color Conversion Chart  
 Inalfa Sunroof Installation Guide  
 2007-2008

Honda	OE Color	2007	2008	Inalfa Sunroof	
<b>Accord Coupe/Sedan</b>	Black	001 Black		<b>Inbuilt 840 4dr</b>	
	Grey	112 Grey			
	Ivory	142 Saddle		<b>Topslider</b>	
<b>2008 Sedan</b>	Grey		092 Stone		
	Ivory		009 Sandstone		
	Black		001 Black		
<b>2008 Coupe</b>	Black		001 Black		
	Ivory		009 Sandstone		
<hr/>					
<b>Civic Coupe</b>	Black	001 Black	001 Black		
	Grey	089 Slate	089 Slate		
	Ivory	009 Sandstone	009 Sandstone		
<hr/>					
<b>SI</b>	Black	001 Black			
<hr/>					
<b>Civic Sedan</b>	Grey	089 Slate	089 Slate	<b>Inbuilt 840 4dr</b>	
	Ivory	009 Sandstone	009 Sandstone		<b>Topslider</b>
<b>Hybrid</b>	Blue	005 Dark Blue		<b>Inbuilt 840</b>	
	Grey	089 Slate			<b>Topslider</b>
	Ivory	009 Sandstone			
<hr/>					
<b>CR-V</b>	Black	001 Black		<b>Inbuilt 840</b>	
	Ivory	009 Sandstone			<b>Topslider</b>
	Grey	089 Slate	089 Slate		
<hr/>					
<b>Element</b>	Black	001 Black	001 Black	<b>Install</b>	
	Grey	112 Grey or 001 Black	112 Grey or 001 Black		<b>Not</b>
	Titanium	001 Black or 087 Ash	001 Black or 087 Ash		
<hr/>					
<b>Fit</b>	Beige	001 Black or 097 Khaki		<b>Inbuilt 840</b>	
	Black	001 Black			<b>Topslider</b>
<hr/>					

<b>Honda</b>	<b>OE Color</b>	<b>2007</b>	<b>2008</b>	<b>Inalfa Sunroof</b>
<b>Odyssey</b>	Ebony	001 Black		<b>Inbuilt 750 Topslider</b>
	Grey	112 Grey		
	Ivory	142 Saddle		
	Olive	093 Shale		
<hr/>				
<b>Pilot</b>	Grey	112 Grey	112 Grey	<b>Inbuilt 840 or 925</b>
	Olive	118 Olive	118 Olive	
	Saddle	073 Beige	073 Beige	
<hr/>				
<b>Ridgeline</b>	Beige	073 Beige	073 Beige	<b>Inbuilt 925 Topslider</b>
	Grey	008 Graphite	008 Graphite	
	Olive	093 Shale	093 Shale	
<hr/>				
<b>S2000</b>	Black			<b>N/A</b>