



OE to Roadwire  
Color Conversion Chart  
Inalfa Sunroof Installation Guide  
2007-2008

Pontiac	OE Color	2007	2008	Inalfa Sunroof
<b>G5</b>	Ebony	001 Black		<b>EVO Short</b>
<b>G6</b>	Ebony Taupe	001 Black 115 Doeskin		<b>Inbuilt 840</b> Sedan <b>Topslider</b> Coupe
<b>Grand Prix</b>	Dk Pewter Parchment	008 Graphite 125 Ivory		<b>Topslider</b>
<b>2008</b>	Cashmere Ebony		094 Desert 001 Black	
<b>Montana SV6</b>	Med Grey Neutral			<b>Inbuilt 840</b> <b>Topslider</b>
<b>Solstice</b>	Black	001 Black	001 Black	<b>N/A</b>
<b>Torrent</b>	Ebony Lt Cashmere Lt Grey	001 Black 009 Sandstone 140 Opal	001 Black 009 Sandstone	<b>Inbuilt 840</b>
<b>Vibe</b>	Dk Charcoal Stone	079 Dk Charcoal 117 Nickel	079 Dk Charcoal 117 Nickel	<b>Inbuilt 840</b> <b>Topslider</b>